


Replacement Parts List for Model # 505 and Model # 506



PN Description

1 Infeed Section Assembly	11 Infeed Bottom Pan Weldment	23 48" Intermediate Section Assembly	35 Drive Section Assembly	47 Guard Weldment
2 • Left Hand Take-up Bar	12 6" Intermediate Section Assy	24 48" Intermediate Frame Weldment	36 Drive Frame Weldment	48 Motor
3 • Right Hand Take-up Bar	13 6" Intermediate Frame Weldment	25 48" Long Bottom Pan Weldment	37 Drive Bottom Pan Weldment	49 Reducer
4 • 1/2" x 6" Take-up Bolt	14 6" Long Bottom Pan Weldment	26 48" Long Siderail	38 Left Hand Drive Plate Weldment	50 Manual Tube Cap
5 • 1 7/16" 3 Bolt Flange Bearing	15 6" Long Siderail	27 84" Intermediate Section Assembly	39 Right Hand Drive Plate Weldment	51 Driven Sprocket
6 Infeed Frame Weldment	16 12" Intermediate Section Assy	28 84" Intermediate Frame Weldment	40 Drive Pulley (9" dia CFRL x 1 7/16")	52 Drive Sprocket
7 Infeed Pulley (8" Dia CF x 1 7/16")	17 12" Intermediate Frame Weldment	29 84" Long Bottom Pan Weldment	41 3/8" x 2 1/2" Tap Bolt	53 Chain
8 Flapper Gate Weldment	18 12" Long Bottom Pan Weldment	30 84" Long Siderail	42 Motor Base	54 Manual
9 24" Long Siderail (Infeed/Intermed)	19 12" Long Siderail	31 120" Intermediate Section Assy	43 40" Long Siderail (Drive Section)	
10 Siderail Coupling	20 24" Intermediate Section Assembly	32 120" Intermediate Frame Weldment	44 Manual Tube Weldment	
	21 24" Intermediate Frame Weldment	33 120" Long Bottom Pan Weldment	45 "Z" Bracket	
	22 24" Long Bottom Pan Weldment	34 120" Long Siderail	46 Guard Back	

• Recommended spare parts to be stocked at your location